

karuun[®]

surface manual - staining

surface steps - finishing

material preparation


1. see „karuun_surface_manual_brushing_sanding_01“

a) process steps - staining

1. first spraying wood stain
 - 2.* optional: brush off excess stain
 3. wait until surface is 100% dry
 - 4.** optional: second spraying wood stain
 - 5.* optional: brush off excess stain
 6. wait until surface is 100% dry
- * only necessary if stain is not applied thin and even
- ** only if higher intensitiy needed

a) detailed steps - staining

1. first spraying wood stain



- spray stain at an angle of 45°
- spray from both sides
- distance 20 cm

***stains containing pigments are protective againsts UV aging**


Stain examples*:



**Zweihorn
„Aquacreativbeize“**




**Votteler Staining
Systems**



a) detailed steps - staining

2. optional: brush off excess stain


3. optional: wait until surface is 100% dry



- brush along capillary direction**
- use medium stiff brush to take out excess stain from the capillary**
- dap brush dry regularly**

a) detailed steps - staining

4. optional: second spraying wood stain



Stain examples*:



**Zweihorn
„Aquacreativbeize“**



**Votteler Staining
Systems**


- spray stain at an angle of 45°
- spray from both sides
- distance 20 cm

***stains containing pigments are protective againsts UV aging**

a) detailed steps - staining

5. optional: brush off excess stain

6. optional: wait until surface is 100% dry



- brush along capillary direction**
- use medium stiff brush to take out excess stain from the capillary**
- dap brush dry regularly**

